



Fiery XF Universal Driver for macOS

The Fiery XF Universal Driver for macOS is a special printer driver that is developed by EFI.

Like a virtual printer, the Fiery XF Universal Driver allows you to print directly to a Fiery XF server on a Windows or Mac computer from any graphics program. However, the Universal Driver has the following advantages:

- You can print to more than one Fiery XF workflow.
- You can make custom settings that override the equivalent workflow settings in Fiery XF. Custom settings can be applied to all jobs, including jobs that you submit from other graphics programs.

This document provides information on how to set up the Fiery XF Universal Driver on macOS. For all other operating systems, follow the steps that are given in the online documentation.

System requirements

To run the Fiery XF Universal Driver, your Mac computer must have one of following operating systems:

- macOS High Sierra 10.13
- macOS Mojave 10.14
- macOS Catalina 10.15
- macOS Big Sur 11

Note: The Fiery XF Universal Driver is supported on x64-bit operating systems only.

Install the Fiery XF Universal Driver

The Fiery XF Universal Driver for macOS is provided as an online update.

- 1 Download the Fiery XF Universal Driver to the computer on which the graphics program is installed.
- 2 The Fiery XF Universal Driver may be available in one of two formats on your computer. Do one of the following with the Fiery XF Universal Driver:
 - Double-click the EFI Universal Driver.pkg.
 - Double-click the EFI Universal Driver.tgz to unzip the installer.
- 3 Double-click Install Fiery XF Universal Driver and follow the on-screen instructions.

To install the Fiery XF Universal Driver, you must have administrator privileges. Consult your system administrator if you require further assistance.
- 4 Click Close to complete the installation procedure.



Add the Universal Driver as a printer

After you have installed the Fiery XF Universal Driver, you need to add it as a printer.

You perform this procedure on the computer that has the Universal Driver installed.

- 1 Select Apple menu > System Preferences, and then select Printers & Scanners.
- 2 Click the + button to add a Printer.
- 3 Click the Advanced icon in the Add window.

If the Advanced icon is not visible, right-click on the toolbar, click Customize Toolbar, and drag the Advanced icon to the toolbar.

- 4 Select Fiery XF Universal Driver from the Type list.
- 5 Type the Fiery XF server IP address in the URL field. This is where you want to print the job with the Universal Driver.

Use the format, **udspooler://ip=10.210.100.52/xf**, where IP is the IP address for the Fiery XF server.

The Name field is filled in automatically with the IP address. You can change the IP address to an easier name to identify the printer.

- 6 Click Other in the Use list to select the Fiery XF Universal Driver PPD.

For macOS 10.13, the PPD is located at Library > Printers > PPDs > en.lproj > EFI_UD_XF.ppd.

For macOS 10.14, 10.15, and 11, the PPD is located at Library > Printers > PPDs > Contents > Resources > en.lproj > EFI_UD_XF.ppd. Click Open to select the PPD.

For macOS 11, the PPD is located at

- 7 Click Add.

The newly added printer with its IP address appears in the list of printers in the Printers & Scanners window.

Print with the Universal Driver

You can print to the Fiery XF server just as you would print to any other printer from a Mac application.

Select the Fiery XF Universal Driver as the default printer in the list of printers, specify print options, and then print the job from the application.

By default, jobs are printed according to the workflow settings in Fiery XF. In the Universal Driver, you can apply job settings that override the workflow settings.

The procedure describes printing from Adobe Illustrator and Adobe Photoshop. Printing from other prepress applications may differ.

- 1 In your application, open the job, and select File > Print.
- 2 Select the Universal Driver from the Printer list, and then click Show Details.

The Show details button is available in most applications. For some applications, such as Adobe Photoshop, you may need to click Print Settings or in Adobe Illustrator, click Setup to view the details if it was selected in the last print session, otherwise the Show details button is shown.

3 Select Fiery XF Universal Driver from the drop-down list.

Depending on the application, Layout may be shown as the selection in the drop-down list.

If you do not need to make job settings before printing, click Print. Your job will be submitted to the default workflow that is set in Fiery XF for the printer.

To make job settings, to change the print settings, or to print to a different Fiery XF workflow, proceed to step 4.

4 To open the Login window for your application, do one of the following:

- Click Setup, and then Change Settings.
- Click Print Settings.

Type the Fiery XF server user name and password in the respective fields and click OK.

5 Select the Workflow preset and Media preset to use for the job when you print with the Universal Driver in the Fiery XF Universal Driver window, and then click OK.

The available workflow and media presets on the Fiery XF server are those created by the users.

If you want to use custom settings in the Workflow preset, click Customize workflow. In the Workflow window, you can specify custom settings for layout, color management and print.

If you want to use custom settings in the Media preset, click Customize media. In the Media window, you can specify custom settings for media configuration and special settings such as cut, printer dryer, and print borderless.

Click Save to save your custom workflow or media settings.

After the settings are saved, manually close the window, and proceed with printing the job with the Universal Driver to the Fiery XF server.

6 Click OK in the Fiery XF Universal Driver window.

7 Click Print.

The job will appear in the Fiery XF server under the selected printer with the settings specified in the Universal Driver.